

Subject: : AmigaOS4

Topic: : Booting off two Internal HDDs in X5K

Re: Booting off two Internal HDDs in X5K

Author: : AmigaSociety

Date: : 2018/11/17 0:25:52

URL:

Tony W on Hyperion Forums answered my question.

```
setenv os4_bootdevice auto
saveenv
```

Did the trick.

Now the 1 and 2 work and I can boot from either of my drives.

TJ