

Subject: : AmigaOS4

Topic: : Why The Sound No Work? x5000- Creative Sound Blaster Live 5.1 Dolby Digital PCI Sound Card (SB0220)

Re: Why The Sound No Work? x5000- Creative Sound Blaster Live 5.1 Dolby Digital PCI Sound Card (SB0220)

Author: : broadblues

Date: : 2017/11/17 19:39:59

URL:

@m1nuto

Quote:

I continue to have issues with the sound card. I don't know what changed, but my installation broke and I had to reinstall OS4.1 again. The Pine Crystal sound card that I purchased was working flawlessly prior to having to reinstall. But, post installation I have to physically remove the sound card from the machine, startup with no sound card in the unit, then hard shutdown, replace the PCI sound card and when it boots up the sound works. If at any point I reboot again, sound is broken again and the process must be re-performed.

I would suggest you don;t repeat that operation too often, every time you do it you risk breaking something.

I can't see why a complete removal of the card would be needed.

On my SAM with a phase22 I sometimes need to reboot a couple of times to get it to initialise the card if the debug kernel is in use. That's a different driver in different hardware, but you might still check which kernel you are using...