

Subject: : AmigaOS4

Topic: : X5000 UBOOT freeze - Fixed

Re: X5000 UBOOT freeze

Author: : LiveForIt

Date: : 2020/1/23 6:31:22

URL:

@derfs

I think UBOOT is saying it does not support your DRAM...

Quote:

```
DRAM: Initializing....using SPD
Detected UDIMM M378B5173EB0-YK0
Not enough bank(chip-select) for CS0+CS1 on controller 0, interleaving disabled!
There is no rank on CS0 for controller 1.
Not enough bank(chip-select) for CS0+CS1 on controller 1, interleaving disabled!
Not all controllers have compatible interleaving mode. All disabled.
```

Detected UDIMM M378B5173EB0-YK0

[https://starmicroinc.net/samsung-4gb-d ... -memory-m378b5173eb0-yk0/](https://starmicroinc.net/samsung-4gb-d...-memory-m378b5173eb0-yk0/)

I can see your RAM sucks, get som ram that is defigned for your computer, who build this computer was this the RAM from Amiga KIT.

wtf... "non-ECC" way... you have cheap ram in your computer. throw the DRAM in the trash!!! and get "ECC" DRAM, check technical manual for correct memory before buying.

And buy a good expensive PSU while your at it, its so typical that they try to sell you some crap... and hope it works out for you should get your money back this type customer service suck..

DO NOT TRY TO FLASH UBOOT BEFORE YOU HAVE GOOD DRAM..