

Subject: : AmigaOS4

Topic: : Cant boot my X5000

Re: Cant boot my X5000

Author: : Joeled

Date: : 2021/4/27 20:19:31

URL:

I got some good advice from Skateman.

>>Unplug the powercord of the PSU

>>Then push the powerbutton.

>>Then plug the powercord back in and try to turn it on.

This solution didnt work.

>> Remove and reset memory from motherboard.

When i did this i got my x5000 to boot again. Maybe there is something wrong with the ram memory?

A big thanks to Skateman 😊