

Subject: : AmigaOS4

Topic: : Cant boot my X5000

Re: Cant boot my X5000

Author: : nbache

Date: : 2021/4/27 23:18:25

URL:

@Joeled

Quote:

>> Remove and reset memory from motherboard.

When i did this i got my x5000 to boot again. Maybe there is something wrong with the ram memory?

Probably not. It most likely just needed a bit of cleaning of the contacts of the RAM boards and/or the sockets, which you provided when you pulled them out and re-inserted them.

For a more thorough effort, you might want to pull them out again and clean the contact surface with a swab with iso or something. And if you can manage, also the sockets. But make sure everything is dry/evaporated before re-inserting and firing up again.

Best regards,

Niels