

Subject: : Amiga Classic

Topic: : How can i detect errors on blank or burned CD/DVDs?

Re: How can i detect errors on blank or burned CD/DVDs?

Author: : Slayer

Date: : 2009/5/20 22:20:26

URL:

@Amigamancer

Not that this will actually help but if something in the day was vital to me I'd copy the entire contents to a harddrive partition... something won't copy if it has a read/write error...

In the instance it is a music cd or movie dvd... simply play the media through...

In my experience errors if any are very rare usually it is a case of burning too quickly or a buggy setup...

btw, do not use cheap media that is a risk you go with...