

---

Subject: : Official AmigaOS4 feedback

Topic: : The A1Floppy thread

Re: The A1Floppy thread

Author: : Ricossa

Date: : 2006/12/27 7:31:29

URL:

@ tonyw:

> What sort of disk is in the drive?

I tryed some old PC formatted disks, both HD and DD

> What does "fdtool (u 0) info" say?

It says:

Version: 52 Revision: 2

Controller state: free

Debug level: 0

Task readiness state: ready

Disk state: drive empty

Drive status: ST0=20 ST1=00 ST2=00 ST3=00

Drive currently on cylinder 1

Driver state:

Interrupt state 0

Data count 0, status count 0

Unit Open count: 3

Change number: 0

Recovered errors this disk: 0

Config word: 00000000

But the drive should not be empty. An I don't get any icon on the WB, so no format possible. What if I want to read PC disks?

Luca